

# Instrument file

```
DEFINE INSTRUMENT My_Instrument(DIST=10)

/* Here comes the TRACE section, where the actual */
/* instrument is defined as a sequence of components. */
TRACE

/* The Ara() class component defines reference points and orientations */
/* in 3D space. */
COMPONENT Origin = Ara()
    AT (0,0,0) ABSOLUTE

COMPONENT Source = Source_simple(
    radius = 0.1, dist = 10, xv = 0.1, yh = 0.1, E0 = 5, dE = 1)
    AT (0, 0, 0) RELATIVE Origin

COMPONENT Emon = E_monitor(
    filename = "Emon.dat", xmin = -0.1, xmax = 0.1, ymin = -0.1,
    ymax = 0.1, Emin = 0, Emax = 10)
    AT (0, 0, DIST) RELATIVE Origin

COMPONENT PSD = PSD_monitor(
    nx = 128, ny = 128, filename = "PSD.dat", xmin = -0.1,
    xmax = 0.1, ymin = -0.1, ymax = 0.1)
    AT (0, 0, 1e-10) RELATIVE Emon

/* The END token marks the instrument definition end */
END
```

Written by you!